


# TSPMYP8M - Second Wi-Fi touch screen for MyPlace


## Quick Installation Guide




**1** Ensure your main MyPlace touch screen is connected to the control box via CABLE12BLUE supplied and has been connected to the home WiFi network.

**NOTE:**

One TSPMYP8 must be installed for the system to function. TSPMYP8 & TSPMYP8M both require a strong WiFi connection for best performance.



**2** Plug the supplied power supply (PSU-DCM) into a power point in ceiling space. Using the 25m CABLE12BLUE & the joiner supplied in the box with TSPMYP8M extend the cable & run it down to the location of your second touch screen (TSPMYP8M).



**3** Connect CABLE12BLUE to the touch screen & attach to your wall then connect to the home WiFi network.

**NOTE:**

On opening the MyPlace app the screen will search for connected systems, this takes approx 6 seconds each time the app is opened.

## NOTE:

**TSPMYP8:** This is the main touch screen & must be plugged into the TOUCH SCREEN port of the control box, every system requires at least 1 x TSPMYP8.

**TSPMYP8M:** This is the optional second screen, it connects as per above to a special PSU-DCM power supply & communicates with the main TSPMYP8 via WiFi.